

# Valley Detail

## W-Valley

Prior to placing, install a second layer of underlayment or water and ice shield centered along each valley. Install W-Valley flashing and secure with galvanized flat screws or galvanized nails. Roof panels are cutback 6 inches. Install underside expandable closure with sealant. Install roof panels and fasten panels through the closure strip and valley into the deck with #9 X 1-1/2" sealing screws.

